

INSTRUCTIONS FOR USING WALLCOVERINGS POLDECOR



STEP 1 - PREPARATION OF THE SUBSTRATE

1. Remove the loose parts and clean and rinse the surface.
2. Fill the cracks, dry them. Surface twice, thoroughly primed with primer (recommended: GRUNT PolDecor, CERESIT CN94 or GRUNTOMAL). GROUNDS DO NOT DILATE!
3. To improve the adhesion and performance of the wallpaper and facilitate its application, it is recommended to add fine sand to the soil (not PolDecor).
4. PolDecor wallpaper should be applied no sooner than 24 hours after the last primer has been applied.



STEP 2 - PREPARING THE PRODUCT

1. Pour the PolDecor wallpaper into the bowl.
2. Pour the right amount of lukewarm water. Thin patterns (type 9, 13/1, 13/2, 17, 18, 20 to 25, 31) are about 4 liters thick (all others) about 6 liters.
3. Mix PolDecor wallpaper manually. The mass should be plastic, dense and lump free. Its consistency should resemble meat to ground cutlets. When the wallpaper is too dense, gradually add water.
4. Let stand for 5 hours and mix again before use.
5. Apply PolDecor wallpaper with a plastic float.
6. Keep it in a cool place for long periods of time.
7. You should make a wall cover once a whole wall.



STEP 3 - TEST METER

1. One pack of PolDecor wallpaper is enough for 3.3 m².
2. To achieve the right material thickness, it is recommended to carry out a mock test of one PolyDecor wallpaper bag on a surface of 3.3 m² (eg cover a 2.5 m area at 1.32 m).
3. This attempt will show you how to apply a thick wallpaper to avoid a situation where the material will be or will run out.

INSTRUCTIONS FOR USING WALLCOVERINGS POLDECOR



STEP 4 - APPLICATION

1. PolDecor wallpaper is applied with a plastic tray. Sandals should be sanded.
2. The pack should be placed parallel to the wall, slightly inclined on one side, distributing the material to its central part, do not perform spherical movements. After each movement, gently tear the pack away, paralleling the wall.
3. Along the edges of the ceiling, doors, windows and corners, apply material from the edge of the wall.
4. On uneven surfaces, the material can be applied directly to the palm.



STEP 5 - STORAGE OF MATERIAL

1. In rooms where we put PolDecor wallpaper, a window must be opened for drying while the water may evaporate.
2. Insert a ventilator to improve air circulation.



WARNING !!!

LIQUID TANKS PolDecor is made from natural ingredients. There is a possibility of a slight difference in shades of wallpaper from different batches. If you do not comply with the instructions,